

Installation Guidelines: Magnolia

3/8" Engineered Hardwood Staple Down Installation

ATTENTION

Inspect ALL materials carefully BEFORE installation. Warranties DO NOT cover materials with visible defects once they are installed.

It is the responsibility of the installer/owner to determine if the job site subfloor and job site conditions are environmentally and structurally acceptable for wood floor installation. Azalea Lane Flooring declines any responsibility for wood floor failure resulting from or connected with subfloor, subsurface, job site damage or deficiencies after hardwood flooring has been installed.

STAPLE DOWN INSTALLATION

Tools: 3/8" products can use a 1 1/4 or 1 1/2 inch 18-gauge staple, 7/32 or 1/4 inch crown or 1 1/4 inch 20 gauge cleat. Do not use staples or nails intended for 3/4 inch solid flooring products.

Wood type sub floors should also be checked for moisture using a reliable moisture meter. Wood or plywood sub floors should not exceed 14% moisture content, the moisture content difference between hardwood flooring and sub floor should not exceed 4%.

SUBFLOOR

5/8" minimum thickness, preferred 3/4" or thicker plywood installed with long edges at a right angle to the 16" on center floor joists and staggered so that the end joints in adjacent panels break over different joists. Nail at each bearing with 6d threaded or 8d common nails spaced 10" on center along intermediate joists.

1" x 4" to 6" wide, square edge, kiln dried coniferous lumber, laid diagonally over 16" on center wooden joists. The ends of all boards are to be cut parallel to the center of the joists for solid bearing. Face nail each board solidly at every bearing on the joists with two nails (7d threaded or 8d common).

23/32" minimum O.S.B. on 19.2-inch minimum center floor joists with system properly nailed or minimum 7/8" subfloor with 24" on center floor joists or trusses.

Baseboards should be installed so that their lower edge is slightly above the level of the finished floor, but not nailed into the finished floor.

Basement and crawl spaces must be dry and ventilated when plank or strip flooring is to be installed over them. In crawl spaces a vapor barrier should be provided. Black vapor barrier must be provided below subfloor on the ground. (6 mil black)

Subfloor should be flat or made to be flat to 3/16" in an 8' ft. radius. Particle board of any thickness is NOT ALLOWED!

Adequate and proper nailing as well as soundness of the subfloor should be ascertained. Foreign material shall be removed from the subfloor surface and swept clean.

The clean subfloor shall be covered wall to wall with 15lb. asphalt saturated felt, (NO ROSIN PAPER). Butt the edges when positioning one or the above mentioned moisture retarder. Double the felt around heat ducts that may be in the floor.

General Staple Down Installation Instructions:

Time at which to install hardwood flooring: Lay only after sheetrock and tile work are thoroughly dried and all but the final woodwork and trim have been completed. The building interior should have been dried and seasoned and a comfortable working temperature (at least 60° F) and a relative humidity of 35 - 55% should exist during and after installation.

DO NOT open until ready to install.

Preparation of subfloor: Subfloor irregularities and undulation may cause any wood flooring installation to develop hollow spots between the flooring and subfloor. These hollow spots are NOT the result of any wood floor manufacturing defect and are NOT covered by warranty.

Adequate and proper stapling as well as soundness of the subfloor should be ascertained. Foreign material shall be removed from the subfloor surface and swept clean.

The clean subfloor surface shall be covered, wall to wall, with 15 lb asphalt saturated felt (NO ROSIN PAPER). Butt the edges of this felt when positioning it.

Laying direction for plank flooring: Flooring should be laid at right angles to the floor joists and, if possible, in the direction of the longest dimension of the room.

Note: Normally, expansion space around the room should be the same distance as the thickness of the hardwood flooring.

The floor should be installed from several cartons at the same time to ensure color and shade mix.

End joints should never be closer than 4" from each other.



Staple Engineered Plank Hardwood Flooring: The first and last row of flooring should be face nailed and filled, as well as staples placed at Tongue. Staple or Nail (cleat) each board along the tongue every 4 to 6 inches apart and within 2 inches of each end joint. This should be done to the entire floor.

NOTES

To avoid movement in hardwood floor relative humidity should be maintained year round at 35-55%. Temperature should be kept between 68°F-78°F year round. The use of matching wood flooring putty to cover small cracks or face nail holes should be considered normal in hardwood flooring installation.

RADIANT HEAT SUBFLOORS (OAK ONLY) – see instructions on next page (Glue Down Installation).

FLOATING INSTALLATION - 3/8", 3" width or wider can be floated in some, not all, installations.



3/8" Engineered Hardwood Glue Down Installation

ATTENTION

Inspect ALL materials carefully BEFORE installation. Warranties DO NOT cover materials that are installed with visible defects.

It is the responsibility of the installer/owner to determine if the job site Subfloor and job site conditions are environmentally and structurally acceptable for wood floor installation. Azalea Lane flooring declines any responsibility for wood floor failure resulting from or connected with subfloor, subsurface, job site damage or deficiencies after hardwood flooring has been installed.

GLUE DOWN INSTALLATION

ADHESIVE: Use the appropriate adhesive, or quality urethane adhesive is recommended.

TOOLS: The required tools for installation of these products include a hammer, hand power saw, chalk line, wood floor adhesive and recommended trowel.

Recommended Trowel: Follow adhesive manufacturer's guidelines.

General Installation Instructions:

Time at which to install hardwood flooring: Lay only after sheet rock and tile work are thoroughly dried and all but the final woodwork and trim have been completed. The building interior should have been dried and seasoned and comfortable working temperature (at least 60°F) should exist during installation.

Preparation of Subfloor:

Subfloor irregularities and undulation may cause any wood floor installation to develop hollow spots between the flooring and subfloor. These hollow spots are NOT the result of any wood floor manufacturing defect and are NOT covered by the Azalea Lane Flooring warranty.

As part of your subfloor preparation remove any existing base, shoe mold or doorway thresholds. These items can be replaced after installation, but should be replaced in such a way as to allow at least ¼" room for expansion around the perimeter of the room. All door casings should be notched out or undercut to allow for ¼" room expansion and to avoid difficult scribe cuts. This is easily done by placing a piece of the engineered product on the subfloor as a height guide for your handsaw or jamb saw.

Note: Normal expansion space around the room should be the same distance as the thickness of the hardwood flooring.

Thoroughly Clean Subfloor:

Remove paint, wax, oil, plaster, "sheet rock mud" and other foreign materials, as well as obvious surface irregularities. #3-1/2 grit open coat paper may need to be used to grind a concrete subfloor. This will loosen any dirt, loose concrete or contaminates. Sweep or vacuum thoroughly. **All previous or existing glues or adhesives must be removed before installing new hardwood floor.** Concrete subfloors must be clean, flat, sound and sufficient compression strength (3000 lbs. P.S.I.) being sure that the surface is NOT slick.

Sections not flat due to waviness, trowel marks, ect. are to be flattened by grinding or the use of leveling compound. Especially along the walls, the subfloor flatness must be checked and if necessary improved. Flatten to 3/16" in 10' radius. In addition to cement subfloors, these wood flooring products can be installed over dry, flat subfloors such as plywood. **No Particle board.**

Time at which to install hardwood flooring: Lay only after sheet rock and tile work are thoroughly dried and all but the final woodwork and trim have been completed. The building interior should have been dried and seasoned and a comfortable working temperature (at least 60° F) and a relative humidity of 35 - 55% should exist during installation.

If subfloor is concrete, check for dryness see below. If moisture is present, do not lay. All concrete subfloors on or below grade need to be tested.

Concrete Subfloor Moisture Testing:

Electrical Impedance Test and Electrical Resistance Test (Concrete Moisture Meters) Follow Moisture Meter MFG Guidelines. If Meter shows possibility of excess moisture further testing is required.

Relative Humidity Test (Standard test method for determining relative humidity on concrete floor slabs using Situ Probes. If test shows over 75% vapor retarder must be used or wait for further curing.

Calcium Chloride Test ASTM F-1869 Readings over 3 lbs and up to 7 lbs vapor retarder needed.

See NWFA installation guidelines chapter 3 Moisture Testing for full information of testing.


Check floor in several locations.

Note: Normal expansion space around the room should be the same distance as the thickness of the hardwood flooring.

- The use of flooring putty to cover small cracks or face nail holes should be considered normal in hardwood flooring installation.

New wood type subfloors should also be checked for moisture using a moisture meter. In general, wood or plywood subfloors should not exceed 14% moisture content and no more than 4% MC difference between wood flooring and subfloor. If the plywood is used as an overlay over the existing subfloor, the thickness of the overlay material must be such as to yield a total 1/2" subfloor thickness.


Suggested Layout Working Line: EXAMPLE: For 3" Material, snap a chalk line 30 1/4" from the wall on the door side of the room. The small area will be your working space and the last to be installed. Temporarily nail straight board on chalk line.



Caution: Proper humidity must be controlled between 35 - 55% for successful performance before, during and after installation.

Installing the floor:

- The floor should be installed from several cartons at the same time to ensure color and shade mix.
- End joints should never be closer than 4 inches from each other. Install tongue into groove.
- Tongue and groove should be engaged by hand. Lift a plank periodically to check adhesive transfer.
- Remove nailed board and install remainder of flooring. Install base and mould after floor installation.
- Clean adhesive off surface of wood with cleaner and soft cloth. (see adhesive manufacturer's recommendations)



Radiant heat subfloors - See below.

Concrete or Plywood: Radiant Heat (OAK ONLY)

Radiant Heat Subfloors on or above grade.

The maximum temperature of subfloor under normal use should not exceed 80°F (Check with heat system manufacturer.)

For correct water temperature inside heating pipes, check with manufacturer's suggested guidelines.

Heating pipes must be covered with 1 ¼ " of concrete or minimum of 1/8" below bottom side of plywood subfloor.

Before installation of hardwood flooring, heat system must be operated at normal living temperature for a minimum of 14 days. One to two days before the flooring is laid, switch off heating unit. (At time of installation, subfloor should be 64°F to 68°F)

Room temperature should not vary more than 15°F season to season. Systems must not exceed 8 watts per square foot heating.